



HP Pavilion DV2160BR Wifi Adapter Replacement

Remove and replace your laptop's wifi adapter.

Written By: Shannon

INTRODUCTION

The Wi-Fi adapter is a crucial piece of hardware in your laptop, allowing access to the Internet via Wi-Fi connection. If you're having problems with connecting to the Wi-Fi, the wifi adapter could be the reason, so you could use this guide to remove and repair or replace the Wi-Fi adapter.




TOOLS:

- [Phillips #1 Screwdriver](#) (1)
 - [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Wifi Adapter




- Start with the bottom of the laptop facing up.
 - Locate the small panel under the battery, which houses the wifi adapter, and unscrew the one 5mm Phillips #0 screw holding the panel in place.
 - Remove the panel and set it aside.
-  Be careful not to snap the 2 tabs on the sides of the panel when pulling it out.

Step 2



- Unscrew the two 3mm Phillips #0 screw which is located at the corners of the wifi adapter.

Step 3



- Pull the 2 black wires with the gold pieces out of the wifi adapter.
- The wifi adapter is now free to be removed.
- ❗ When reconnecting the wires for re-installing the wifi adapter, make sure the gold ends are rotated correctly to be properly pushed back in.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 07:28:45 PM.